ASUS

Padfone™

User Manual

Downloaded from www.vandenborre.be

E7189
First Edition
October 2012

Copyright © 2012 ASUSTek Computers, Inc. All Rights Reserved.

No part of this manual, including the products and software described in it, may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language in any form or by any means, except documentation kept by the purchaser for backup purposes, without the express written permission of ASUS Telecom (“ASUS”).

Product warranty or service will not be extended if: (1) the product is repaired, modified or altered, unless such repair, modification of alteration is authorized in writing by ASUS; or (2) the serial number of the product is defaced or missing.

ASUS PROVIDES THIS MANUAL “AS IS” WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL ASUS, ITS DIRECTORS, OFFICERS, EMPLOYEES OR AGENTS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFITS, LOSS OF BUSINESS, LOSS OF USE OR DATA, INTERRUPTION OF BUSINESS AND THE LIKE), EVEN IF ASUS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES ARISING FROM ANY DEFECT OR ERROR IN THIS MANUAL OR PRODUCT.

SPECIFICATIONS AND INFORMATION CONTAINED IN THIS MANUAL ARE FURNISHED FOR INFORMATIONAL USE ONLY, AND ARE SUBJECT TO CHANGE AT ANY TIME WITHOUT NOTICE, AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY ASUS. ASUS ASSUMES NO RESPONSIBILITY OR LIABILITY FOR ANY ERRORS OR INACCURACIES THAT MAY APPEAR IN THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT.

Products and corporate names appearing in this manual may or may not be registered trademarks or copyrights of their respective companies, and are used only for identification or explanation and to the owners’ benefit, without intent to infringe.

Downloaded from www.vandenborre.be

Table of Contents

Package contents.....5

Chapter 1: Using your PadFone 2

Basics.....6
- Navigating your PadFone 2.....7
- Making calls.....8
- Setting up your contacts list.....8

Connecting to the world.....9
- Connecting to mobile networks.....9
- Connecting to Wi-Fi networks.....10
- Using Bluetooth.....11

Chapter 2: Using your PadFone 2 Station

Basics.....14
- Unlocking your device.....14
- Entering the camera mode.....14
- Tutorial.....15
- Home Screen.....16
- Screen Views.....17

Chapter 3: Touching and typing

Using gestures.....18
Using the onscreen keyboard.....19
Using Google voice typing.....20

Chapter 4: Using apps and widgets

Using apps on the PadFone 2.....21
- Launching apps.....21
- Messaging.....21
- Surfing the web.....22
- Managing notifications.....22
- Searching your PadFone 2 or web.....25
- Taking pictures.....25
- Watch Calendar.....26
- SuperNote.....27

Downloaded from www.vandenborre.be

Using apps on the PadFone 2 Station 29
Managing Apps 29
Task Manager 33
File Manager 34
Play Store 37
Settings 39
Music 42
Gallery 43
Camera 47
Email 49
Gmail 51
MyLibrary 53
Places and Maps 56
Polaris® Office 57
MyNet 59
App Locker 63
SuperNote 64
Watch Calendar 66
Using PadFone 2 widgets 67
Adding widgets 67
Task Manager 68
Using PadFone 2 Station widgets 69
Adding widgets 69
ASUS Battery 70

Downloaded from v.vandenborre.be

Package contents

Item	PadFone 2	PadFone 2 Station	2-in-1 set
PadFone 2	•		•
PadFone 2 Station		•	•
Power adapter	•		•
PadFone 2 signal cable	•		•
Headset	•		•
Quick Start Guide	•	•	•
Important Notices	•		•
Warranty card	•	•	•

NOTES:

- ASUS PadFone 2 and PadFone 2 Station are purchased separately.
- Contact your retailer if any of the items is damaged or missing.

Downloaded from www.vandenborre.be

1 Using your PadFone 2

Use your PadFone 2 to enjoy the latest features and technologies of Android 4.0 (Ice Cream Sandwich) operating system. Do work and play on your PadFone 2 to fully appreciate the tons of interactive applications and features, and the seamless connectivity solutions in data sharing and communication that Android 4.0 has to offer.

Basics

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** to prevent injury or damage to your device.
- Refer to your **PadFone 2 Quick Start Guide** for instructions on installing the SIM card, installing an SD card, installing the battery, and charging your device.

The first time you turn on your PadFone 2, you'll see the Welcome screen.

Touch the menu to choose your preferred language and touch **Next Step**. Follow the succeeding instructions to set up your PadFone 2.

NOTES:

- You can skip some of the steps and set them up later.
- You can press the power key for 10 seconds to reset the system.

Downloaded from www.vandenborre.be

Navigating your PadFone 2

After you finish setting up your PadFone 2, the Home Screen appears.



At the bottom of your Home Screen, you'll find three navigation icons , , . These icons, which are always available on the system bar, allow you to instantly jump back to the Home Screen, return to a previous page, or launch a recent app.

Icon	Description
	Allows you to go back to the previous screen, until you are in the Home Screen.
	Opens your Home Screen.
	Opens a thumbnail list of your most recent apps. To launch an app, touch the thumbnail image. If you wish to remove a thumbnail app, swipe it to the left or right.

Downloaded from www.vandenborre.be

Making calls

To make a call:

1. Touch on the Home Screen or touch to go to the All apps screen.
2. Touch the keys to key in the number you wish to call.
3. Touch to dial.
4. Touch to end the call.

Setting up your contacts list

To set up your contacts, you can do any of the following:

- Touch then select **Create a new contact**. Follow the succeeding screen instructions to add a new contact.
- Import your contacts from your SIM card into your PadFone 2. To import your contacts from your SIM card:

  1. Install the SIM card into your PadFone 2.
  2. From the Home Screen, touch to launch the People app.
  3. Touch **Import/export contacts**.
  4. Touch **Import from SIM card**. When prompted, select to which account you want to add the contacts.
  5. To import the contacts one at a time, touch to select a contact you wish to import, then touch **OK**. When prompted, touch **OK** to confirm.

Downloaded from www.vandenborre.be

Connecting to the world

Connecting to mobile networks

After installing the SIM card, you are ready to use your PadFone 2 to make/receive voice calls or transmit/receive data. Different countries or regions may have different mobile networks available and you may have to configure your PadFone 2 to access these networks.

To configure your Mobile networks setting:

1. Do any of the following to go to the Settings screen:
   - Touch to go to the All apps screen then touch **Settings** .
   - Swipe your finger down from the top of the screen to go to **ASUS Quick Settings** then touch .
2. From the Settings screen, touch **More....**
3. Touch **Mobile networks.**

NOTE:

- For more details about ASUS Quick Settings, refer to the section **Managing notifications** in Chapter 4.

IMPORTANT:

- If your PadFone 2 does not connect to a network, contact your mobile network carrier for assistance.
- Refer to your **PadFone 2 Quick Start Guide** for instructions on how to install a SIM card.

Downloaded from www.vandenborre.be

Connecting to Wi-Fi networks

Wi-Fi wireless networking technology allows you to exchange data wirelessly over a network. To use Wi-Fi, enable the Wi-Fi feature in your PadFone 2 and connect to a wireless network. Some wireless networks are secured with a key or protected with digital certificates and requires additional steps to set up; others are open and you can easily connect to them.

TIP:

Turn OFF Wi-Fi when you're not using it to help save battery power.

To enable Wi-Fi and connect to a Wi-Fi network:

1. Do any of the following to go to the Settings screen:
   - Touch to go to the All apps screen then touch **Settings** .
   - Swipe your finger down from the top of the screen to go to **ASUS Quick Settings** then touch .
2. Slide the Wi-Fi switch to **ON**. When enabled, your PadFone 2 scans for available Wi-Fi networks.
3. Touch **Wi-Fi** to display list of available Wi-Fi networks nearby. Secured networks are indicated with a lock icon.
4. Touch a network name to connect to it. If the network is secured or protected, you are prompted to key in a Password or key in other credentials.

NOTE:

For more details about ASUS Quick Settings, refer to the section **Managing notifications** in Chapter 4.

IMPORTANT:

If your PadFone 2 finds a network that you have connected to previously, it automatically connects to it.

Downloaded from www.vandenborre.be

Using Bluetooth

Enabling or disabling Bluetooth in your device

Bluetooth is a wireless standard used for exchanging data over short distances. Bluetooth exists in many products, such as smartphones, computers, tablet devices, and headsets.

Bluetooth is very useful when transferring data between two or more devices that are near each other.

The first time you connect to a Bluetooth device, you must pair it with your PadFone 2.

TIP:

Turn OFF Bluetooth in your PadFone 2 when you're not using it to help save battery power.

To enable or disable Bluetooth in your PadFone 2, you can do any of the following:

- Touch to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON** / **OFF**.
- Swipe your finger down from the top of the screen to go to **ASUS Quick Settings**, touch , and touch **Bluetooth** .

Downloaded from www.vandenborre.be

Pairing your PadFone 2 with a Bluetooth device

Before you can connect to a device, you must first pair your PadFone 2 to that device. Once paired, the devices stay paired unless you unpair them.

To pair your PadFone 2 to a device:

1. Touch to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. Touch **Bluetooth** to display all available Bluetooth devices within range. If the device you want to pair with is not in the list, ensure that its Bluetooth feature is turned ON and set as Discoverable. See the technical documentation that came with the device to learn how to turn its Bluetooth ON and how to set it to discoverable.
3. If your PadFone 2 has finished scanning before your Bluetooth device is ready, touch **Search for devices**.
4. In the list of available devices, touch the Bluetooth device you want to pair with. Follow the succeeding screen instructions to complete the pairing. If necessary, refer to the technical documentation that came with the device.

Connecting your PadFone 2 to a Bluetooth device

After you have paired your PadFone 2 to a Bluetooth device, you can easily reconnect to it again manually, after it is back in range.

To connect:

1. Touch to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. In the list of **PAIRED DEVICES**, touch the name of the paired device.

Downloaded from www.vandenborre.be

Unpairing and configuring a Bluetooth device

To unpair or configure a Bluetooth device:

1. Touch to go to the All apps screen then touch **Settings** . Slide the Bluetooth switch to **ON**.
2. Touch **Bluetooth** to display the Bluetooth settings.
3. Touch the Bluetooth Quick Settings icon beside the connected Bluetooth device you want to unpair or configure.
4. From the Bluetooth Quick Settings screen, you can do any of the following:
   - Touch **Unpair** to unpair the device.
   - Touch **Rename** to rename the Bluetooth device.
   - Touch any of the listed profiles to enable or disable profile.
5. Touch when you're finished.

Downloaded from www.vandenborre.be

2 Using your PadFone 2 Station

Install your PadFone 2 into your PadFone 2 Station to extend its battery life and turn it into a tablet device.

IMPORTANT:

- Before you start, ensure that you have read all the safety information and operating instructions in the **Important Notices** bundled with your PadFone 2 to prevent injury or damage to your device.
- Refer to your **PadFone 2 Station Quick Start Guide** for instructions on inserting your PadFone 2 into the PadFone 2 Station.

NOTES:

- The image used is for reference only and may look different on your PadFone 2 Station.
- The Home Screen may update and change with Android OS.

Basics

Unlocking your device

To unlock your device, touch and drag the lock icon out of the circle to the open locked icon.

Entering the camera mode

To enter into **Camera** mode, touch and drag the lock icon out of the circle to the camera icon.

Downloaded from www.vandenborre.be

Tutorial

Tutorial automatically starts the first time that you install your PadFone into your PadFone 2 Station. It offers useful insights about the seamless possibilties of using the PadFone and PadFone 2 Station.

To access it again, swipe your finger to the right and touch **Tutorial** from the Home Screen.

Expand Your World
Phone and Pad mode to fulfill your whole day's needs.
Always on, always connected.
Tutorial
You can find this tutorial on the Home screen.
Start
8:13

Downloaded from www.vandenborre.be

Home Screen

Display local weather information. Touch to customize weather widget settings, location, and frequency updates.
Open Google Text search
Open Google Voice search
Open All apps screen
Shortcuts
Notification area & Settings
Displays local date
Display recent apps
Return to Home Screen
Return to the previous screen
Displays your e-mail inbox. Touch to configure the email account for the first time, and touch to read e-mails in the e-mail inbox folder.

Downloaded from www.vandenborre.be

Screen Views

The screen view rotates automatically when you hold the tablet horizontally to vertically, and vice versa.

To enable/ disable Auto-rotate screen, go to **Settings** > **Display**.

Landscape view

Portrait view

Downloaded from www.vandenborre.be

3 Touching and typing

Using gestures

Use your fingers to launch apps, move icons, select menu items, press buttons, type on the onscreen keyboard, and perform other useful gestures on your Padfone 2 device's touchscreen.

To key in or type something, touch the part where you need to type and the onscreen keyboard will pop up.

The following table describes more useful gestures.

Gesture	Description
Pinch	Place two fingers on the screen and spread them apart to zoom in and bring them together to zoom out. This gesture can be used in selected apps, including Maps, Gallery, and Browser.
Drag	Touch and hold an icon or item then, without lifting your finger, move your finger on the screen to move the icon or item.
Touch and hold	Touch and hold an item until an action occurs.
Swipe or slide	Quickly move your finger across the screen in one sweeping motion.
Double-tap	Quickly tap twice on the screen to zoom.

Downloaded from www.vandenborre.be

Using the onscreen keyboard

You can type text using the onscreen keyboard.

In most apps, the onscreen keyboard appears automatically when needed. In other apps, you can touch where you need to type to open the onscreen keyboard.


1 2 3 4 5 6 7 8 9 0
q w e r t y u i o p
a s d f g h j k l
z x c v b n m
1@#
_ @ .com .
Next
Touch to turn caps lock ON, Fixed ON, or OFF. When ON, the alphabet keys are shown in capital letters
Touch to hide onscreen keyboard
Touch and hold to select input method
Touch for back space
Touch to toggle between numeric pad with special characters and QWERTY keyboard

While typing on the onscreen keyboard, the keyboard displays suggestions that may match the text that you need. Touch a suggestion to use it.

Downloaded from www.vandenborre.be

Using Google voice typing

Google voice typing uses Google's speech-recognition technology, that converts spoken words into text input. You must be connected to the Internet when using this feature.

As you speak, the converted text is underlined and you can continue speaking to keep it, or you can delete it.

To use Google voice typing:

1. Touch text field where you want to type text.
2. Depending on the app you're using, you can do either of the following:
   - If you see the microphone icon beside the text field, touch it.
   - If the onscreen keyboard is open, touch then when prompted to **Select input method**, touch **Google voice typing**.
3. When you see the microphone icon, speak clearly what you want to type. When you pause, Google voice typing transcribes the text you spoke and displays it on the text field.

TIPS:

- Say "period", "comma", "question mark", or "exclamation point" to type these punctuation marks.
- Touch the Backspace key to delete the underlined text.

Downloaded from www.vandenborre.be

4 Using apps and widgets

You can seamlessly use applications between your PadFone 2 and PadFone 2 Station.

NOTES:

- PadFone 2 and PadFone 2 Station are purchased separately.
- Some downloaded applications may work on your PadFone 2 but may not work on your PadFone 2 Station, and vice versa.

Using apps on the PadFone 2

Launching apps

Touch to display all your apps. The main apps screen is where you can see all your apps. From the main apps screen you can:

- Touch an icon to launch an app.
- Swipe the screen to display more apps.
- Drag an app icon into the Home Screen.
- See apps compatible with the PadFone 2 Station.
- Explore widgets.
- Get more apps from the Play Store.

Messaging

Touch to compose and send a message.

Downloaded from www.vandenborre.be

Surfing the web

Touch to launch the browser and surf the web.

Managing notifications

Notifications alerts you about new messages, calendar events, media service connections, PC sync information, alarms, and more.

Enable the ASUS Quick Setting app to see more and do more from your Notifications area.

NOTES:

- If ASUS Quick Setting is not enabled, go to the All Apps screen, touch then select **ASUS customized setting** and enable **Use ASUS Quick Setting**.
- Depending on your sound settings, you will also hear a sound at the same time a notification icon is displayed on the top left of your screen - everytime a new notification arrives.

To see your notifications, swipe your finger down from the top of the screen.

Downloaded from www.vandenborre.be

ASUS Quick Setting



Downloaded from www.vandenborre.be

	Description
	Touch to enable or disable the Wi-Fi connection.
	Touch to enable or disable Mobile Data function.
	Touch to enable or disable Smart Saving function.
	Touch to enable or disable Instant Dictionary app.
	Touch to enable or disable Wi-Fi Hotspot function.
	Touch to enable or disable the Bluetooth connection.
	Touch to enable or disable the GPS function.
	Touch to enable or disable the vibrate feature.
	Touch to enable or disable the auto-rotate screen feature.

Downloaded from www.vandenborre.be

Searching your PadFone 2 or web

Use the Google Search bar at the top of your Home Screen to help you find anything that you need from your PadFone 2 or from the web. To start searching, you can do either of the following:

- Touch Google on the search bar then key in your search item. As you key in your search item, Google lists suggestions that may match your search, touch a suggestion to search for it immediately or touch the arrow beside it to add the term into the search field.
- Touch then when prompted to **Speak now**, speak clearly the item you're searching.

Taking pictures

Use the camera app, taking pictures and videos with your PadFone 2 is fun and easy.

The camera app works with two cameras, one 1.2 megapixel camera at the front of your device and one 13 megapixel camera at the rear.

The front camera allows you take pictures and videos, while the rear camera allows you to take high resolution pictures and videos. The rear camera also allows you to take pictures in Panorama mode, where you can pan across a subject to create a single picture.

You can view your pictures and videos in the Gallery app.

To start taking pictures or video, go to the Home screen or All Apps screen and touch

> .

Downloaded from www.vandenborre.be

Watch Calendar

Watch Calendar allows you to add, edit, and delete an event or appointment and sync it through your Gmail account.



To launch Watch Calendar:

1. Touch to go to the All apps screen then touch **Watch Calendar** .
2. To add an event or appointment, touch .
3. Key in the event name, date and time, location and description of the event. To attach a file, touch + and select a file from the Gallery.
4. Touch **Done**.
5. To edit the selected event, touch . Touch to delete the selected event.

Downloaded from www.vandenborre.be

SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone 2. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and a lot more.

To launch SuperNote, touch to go to the All apps screen then touch **SuperNote** .

Downloaded from www.vandenborre.be

Using SuperNote

To create a new notebook:

1. Touch **New Notebook**.
2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone 2.



NOTE:

- For more details using SuperNote on your PadFone 2, tap **Tutorial for Phone**.

Downloaded from www.vandenborre.be

Using apps on the PadFone 2 Station

Managing Apps

App shortcut

You can create shortcuts for your favorite apps on your PadFone 2 Home Screen.

1. Touch to go to the All apps screen.
2. From the **All apps screen,** touch and hold the icon of the app you wish to move then drag and place the app on the Home Screen.

App info

You can view the detailed app information while you are creating a shortcut for the app. While holding an app from the All apps screen to the Home Screen, the **App info** will appear on the top of the Home Screen page. Drag the app to **App info** to display its detailed information.

Downloaded from www.vandenborre.be

Removing App from Home Screen

You can remove app shortcuts from your PadFone 2 Home Screen. The original app will remain in your **All apps** screen. To remove an app in your Home screen:

1. Touch and hold an app on your Home Screen until **X Remove** appears.
2. Drag the app to **X Remove** to remove it from the Home Screen.

Downloaded from www.vandenborre.be

App Folder

Create folders to organize your applications and shortcuts on your PadFone 2 Station Home Screen.

1. On your PadFone 2 Station's Home Screen, touch and drag an app or shortcut onto another app and a folder will appear.
2. Touch the new folder and tap **Unnamed Folder** to rename the folder.


Organize your apps with folders
To make a new folder on your Home screen, stack one app on top of another.
OK
MyZine
TRAVEL
12:00



Downloaded from www.vandenborre.be

Recent Apps

Recent apps are displayed on the left panel of the Home Screen. You can find detailed information and manage your apps from the Recent Apps list.

1. Touch the **Recent Apps** icon at the lower left corner of the Home Screen.

2. Swipe up or down the list to view **Recent Apps.** Swipe a recent app to the left or right to remove from the list.
3. Touch and hold a recent app to display the menu. Select to remove app from list or display app information.

Downloaded from www.vandenborre.be

Task Manager

ASUS widget displays a list of currently running utilities and applications and their usages in percentages on your PadFone 2 Station.

1. Touch to go to the All apps screen.
2. Touch **WIDGETS** to display the widgets menu.
3. Touch and hold **ASUS Task Manager** to display the ASUS Task Manager box on the Home Screen.

4. Touch and hold the widget to display the sizing brackets. Pull the sizing bracket upward or downward to show the complete list of tasks.
5. Tap beside each running app to close the app. Touch **Close All** to close running apps all at once.

Downloaded from www.vandenborre.be

File Manager

File Manager allows you to easily locate and manage your data either on the internal storage device or the connected external storage devices.

To access the internal storage device:

1. Touch to go to the **All apps** screen.
2. Go to **All Apps** screen, touch **File Manager**, then go to **My Storage.**



3. The Internal Storage (/sdcard/) and any connected external storage devices (/Removable/) are displayed on the left panel. Touch the source icon on the left panel to display the content list, and touch to select an item.



Downloaded from www.vandenborre.be

4. Touch the **Return** folder icon to return to the root directory of **My Storage.**



To access the external storage device:

1. Touch the USB or SD card icon on the bottom right corner of your Home Screen to display the notification box.

Downloaded from www.vandenborre.be

2. Touch the folder icon to display its contents.



To copy, cut, delete, or share files:

Tick the file you wish to copy, cut, share, or delete and touch the action icon found at the tool bar on the upper right corner of the File Manager screen.

You can also tick the file and drag/drop it to your desired destination folder.



Downloaded from www.vandenborre.be

Play Store

Access lots of fun games and tools in the Play Store using your Google account. If you don't have a Google account, please create one.

To access the Play Store:

1. Touch to go to the All apps screen.
2. From the All apps screen, tap **Play Store** .
3. You need a Google account to access Google Play. If you don't have an existing account, tap **New**.



4. Type your **Email** and **Password** to **Sign in** if you already have an account.



Downloaded from www.vandenborre.be

5. After signing in, you can start downloading and adding apps to your device from the Play Store.

IMPORTANT:

Download the latest Adobe Flash Player version 11.1.112.60 for ICS devices.

NOTES:

- You cannot restore the deleted applications, but you can login with the same ID and download them again.
- Some applications are free and some might charge you through a credit card.

Downloaded from www.vandenborre.be

Settings

Settings screen allows you to configure the settings of your PadFone 2 Station, including **Wireless & networks, Device, Personal,** and **System** settings. Touch the tabs on the left to switch screens and do the configurations.

There are two ways to go to the **Settings** screen.

From the **All apps screen:**

Touch **Settings** to display the settings menu.

Downloaded from www.vandenborre.be

From **ASUS Quick Setting:**

Touch the notification area on the bottom right corner to launch the **ASUS Quick Settings** panel.



Downloaded from www.vandenborre.be

ASUS Quick Setting Adjustment Panel

Touch any of the following icons to enable or disable its assigned function.



IMPORTANT:

- **Balanced mode [Default mode]:** Balances the system's performance and power usage.
- **Performance mode:** Maximizes the system's performance but consumes more battery power.
- **Power saving mode:** Energy saving mode

Notification Panels

Notification panels will appear under the Quick Setting panel for alerts or updates in apps, incoming emails, and utillity status.



IMPORTANT:

Swipe a notification to the right or to the left to remove item from the list.

Downloaded from www.vandenborre.be

Music

Touch **Music** on the Home Screen to play your music files. This application automatically collects and displays all the audio files stored in your PadFone 2 Station and connected external storage devices.

You can shuffle and play all audio files randomly or flip to select an album for your listening pleasure.

Use the buttons on the top to conveniently sort or search your audio files.



- **NOTE:**
  The audio and video codec supported by your PadFone 2 Station:
  Decoder
  Audio Codec: AAC LC/LTP, HE-AACv1(AAC+), HE-AACv2(enhanced AAC+), AMR-NB, AMR-WB, MP3, FLAC, MIDI, PCM/WAVE, Vorbis, WAV a-law/mu-law, WAV linear PCM, WMA 10, WMA Lossless, WMA Pro LBR
  Video Codec: H.263, H.264, MPEG-4, VC-1/WMV, VP8

  Encoder
  Audio Codec: AAC LC/LTP, AMR-NB, AMR-WB
  Video Codec: H.263, H.264, MPEG-4

Downloaded from www.vandenborre.be

Gallery

Touch **Gallery** on the Home Screen to browse for images or video files. This app automatically collects and displays all the images and video files stored in your PadFone 2.

From the Gallery, you can display images in a slideshow or touch to select for image or video files.

You can also use the menu buttons on the upper right corner of the Gallery screen to sort the files by album, by location, by time, by people, or by tags.



Downloaded from www.vandenborre.be

Sharing and deleting albums

Touch and hold an album in the Gallery until the Tool bar on top appears.

Using the Tool bar options, you can upload, delete, or share selected albums online.





Share the selected album through ASUS Webstorage, Bluetooth®, Picasa®, Google+®, or Gmail®



Delete or cancel the selected album

Downloaded from www.vandenborre.be

Sharing, deleting, and editing images

Touch an image in the Gallery and use the tool bar on the upper right corner to share, delete, or edit a selected image.





Share the selected album through ASUS Webstorage, Bluetooth®, Picasa®, Google+®, or Gmail®



Delete or cancel the selected album



Check the image information, and edit the selected image

CAUTION!

You cannot restore a deleted file.

Downloaded from www.vandenborre.be

Gallery widget

The **Photo Gallery** widget allows immediate access to your favorite photos or albums right from the Home Screen.

1. Touch to go to the All apps screen.
2. Touch **Widgets** to display the widgets menu.
3. Touch and hold **Photo Gallery** until the gallery widget box moves to the Home Screen and displays the **Choose images** menu box.
4. Choose the album or image that you wish to place as a widget on the Home Screen.



Downloaded from www.vandenborre.be

Camera

Touch or from the Home screen or All apps screen to take pictures, record videos, or create panoramic images. You can use the front camera or the back camera to take pictures or record videos.



Camera mode



Downloaded from www.vandenborre.be

Video mode

Panoramic mode



Panoramic image

Downloaded from www.vandenborre.be

Email

Email allows you to add several e-mail accounts and conveniently browse and manage your e-mails.

To set up an email account:

1. Touch to go to the All apps screen.
2. Touch **Email** to launch the email app.
3. From the email app screen,key in your **Email address** and **Password**, then touch **Next**.

4. Wait while your PadFone 2 automatically checks your incoming and outgoing mail server settings.

5. Configure the **Account options** and touch **Next**.



Downloade
ndenborre.be

6. Provide a name for the account and key in the name you want displayed on the outgoing messages. Touch **Next** to log into your mail inbox.



To add email accounts:

1. Touch to go to the All apps screen, touch **Email** and login using the account that you've previously set up.
2. Touch **Settings** on the upper right corner to display the preferences for this account.
3. Touch **Add account** on the upper right corner to add another account.





NOTE:

You can include all your e-mail accounts in **Email**.

Downloaded from www.vandenborre.be

Gmail

Gmail (Google mail) allows you to access your Gmail account, receive, and compose e-mails.

To set up a Gmail account:

1. Touch **Gmail** from the **All apps** screen.

   Touch **Existing** and type your existing **Email** and **Password**, then touch **Sign in**.



NOTE:

Touch **New** if you do not own a **Google Account**.

2. Wait while your PadFone 2 communicates with Google servers to set up your account.



Downloaded from manuals.vandenborre.be

3. You can use your Google account to backup and restore your settings and data. Touch **Done** to sign in to your Gmail.



IMPORTANT:

If you have several e-mail accounts in addition to Gmail, use **Email** to set up and access all your e-mail accounts at same time.

Downloaded from www.vandenborre.be

MyLibrary

MyLibrary, an integrated interface for your e-book collections, allows you to place your purchased or downloaded e-books into different bookshelves and genres.

Touch to go to the All apps screen, then touch MyLibrary.

NOTE:

Log into asus@vibe to download more e-books.

IMPORTANT:

- MyLibrary supports e-books in ePub, PDF and TXT format.
- You may need Adobe Flash® player to open some e-books. Download Adobe Flash® player before using MyLibrary.



Downloaded from www.vandenborre.be

Reading your e-books

To read e-books:

1. Touch to select an e-book on the bookshelf.
2. Touch and hold the screen to show the tool bar on the top.



NOTES:

- Android initiates the download and installation of necessary resource if you would like to use the text-to-speech function.
- Tap on the Bookmark list and select the marked page to show the bookmark icon on the upper right corner of the screen.

Downloaded from www.vandenborre.be

3. Flip pages like a real book or move the page scroll at the bottom.



Making notes on your e-books

1. Touch and hold on a desired word or sentence until the tool menu and the dictionary definition are displayed.



2. Once selected, you either highlight the selected word with a marker, add a note, use text-to-speech function for the selected text, or simply copy the word.
3. Move the selection point to extend the selected region to a whole phrase or sentence if needed.

Downloaded from www.vandenborre.be

Places and Maps

Google Places

Google Places allows you to easily find places such as nearby attractions, restaurants, coffee shops, or gas stations. It also allows you to check in your current location at a specific time and share this information with others.

Google Maps

Google Maps allows you to find establishments, view maps, and get directions. Use the tool bar on the top to get directions or create your own maps.



Downloaded from www.vandenborre.be

Polaris® Office

Polaris® Office is a set of interrelated desktop applications that allows you to create, read, and edit documents, spreadsheets, and presentations.

To use Polaris® Office:

1. Touch to go to the All apps screen.
2. In the **All apps screen**, touch **Polaris® Office**.

3. Touch any of the following:
   - Touch **Browser** to view the files/folders in the local storage.
   - Touch **Clouds** to add a cloud service account.
   - Touch **Form type** to view all documents by type.
   - Touch **Favorites** to view your favorite files.

Downloaded from www.vandenborre.be

Adding new files

To add new files, touch ⋮ then select **New**:

- Touch **Document (.doc)** or **Document (.docx)** to start the word processor to edit documents.
- Touch **Sheet (.xls)** or **Sheet (.xlsx)** to start the spreadsheet to perform calculation and manage information.
- Touch **Slide (.ppt)** or **Slide (.pptx)** to start the application to create and share presentations.
- Touch **Text** to create text files.

Adding Accounts

You are allowed to edit your files with Polaris® Office from other accounts, including **Google docs** and **Box.net**.

1. Touch **Clouds**.
2. Select a desired service to add.
3. Key in your e-mail account and password and touch **OK** to add the account.



Downloaded from www.vandenborre.be

MyNet

MyNet allows you to store, save, and stream audio, video, and image files between your PadFone 2 Station and a DLNA device such as your computer, TV, or speakers.

NOTE:

DLNA (Digital Living Network Alliance) is the networking standard that allows network devices to seamlessly communicate with each other.

•

IMPORTANT:

- MyNet works with Microsoft Media Player 11 or later version only.
- MyNet will not work if the devices are connected via 3G network.
- Your PadFone 2 Station and the DLNA device such as computer, TV, or speakers must be connected to the same wireless network. Otherwise, MyNet will not function.

1. Ensure that your PadFone 2 Station and your computer are connected to the same wireless network.
2. Click and enable **Allow remote control of my Player** and **Automatically allow devices to play my media** in Windows Media Player on your computer. Go to **More streaming options** to configure, if necessary.



Downloaded from www.vandenborre.be

3. On the **Server** list, select the source device on the left panel to view the contents.



4. You can do any of the following:

- Select a file and touch **Play to** on the bottom right to start playing on the target device.



Downloaded from www.vandenborre.be

- Touch and hold a file to upload or download it to and from the connecting devices.



- You can also select a file from the **Playlist**. The Playlist offers a common space for the connected devices to share files. Tap the plus sign (+) to create new lists.



Downloaded from www.vandenborre.be

5. To enable **Digital Media Server**, touch **Settings** on the upper right corner and tick **Digital Media Server Settings** to allow the other connecting devices to access media files on your PadFone Station. You can also select the location of the file you want to share.



Downloaded from www.vandenborre.be

App Locker

App Locker allows you to password-protect your apps.

To use **App Locker**:

1. From the **All apps** screen, touch on **App Locker** .
2. Set up your password.
3. Tick the apps you would like to lock.

4. Activate App Locker from Settings on the upper right corner.

NOTES:

- Locked apps will have lock icons on the Home Screen.
- You will be asked for your password everytime you access the locked apps.

Downloaded from www.vandenborre.be

SuperNote

SuperNote is a convenient app used for writing and painting on your PadFone 2 Station. You can take notes, send instant messages, draw sketches, create e-cards with audio recordings or diaries with video, and lots more.



Downloaded from www.vandenborre.be

Using SuperNote

To create a new notebook:

1. Touch **New Notebook**.
2. Key in a name for the file and choose the notebook type to start writing on the page.

The following screen describes the SuperNote screen features on your PadFone 2 Station:



NOTE:

- For more details using SuperNote on your PadFone 2 Station, tap **Tutorial for Pad**.

Downloaded from www.vandenborre.be

Watch Calendar

Watch Calendar allows you to add, edit and delete an event or appointment and sync it through your Gmail account.

1. From the **All apps** screen, touch **Watch Calendar**.
2. To add an event or appointment, touch **New Event**.

3. Key in the event name, date and time, location and description of the event. You can also attach a file by touching **+** then selecting a file from the Gallery.
4. Touch **Done**.

To edit an event, touch the event name and touch **Edit**.

Touch **Delete** to delete the selected event.

Downloaded from www.vandenborre.be

Using PadFone 2 widgets

Adding widgets

Widgets are useful and fun applications that brings information and services conveniently to your Home Screen at-a-glance. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch on your Home Screen then touch the Widgets tab at the top of screen.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- Swipe left or right to move between screens and view more widgets.

IMPORTANT:

- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
- If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.

To remove a widget:

- Touch and hold the widget until **X Remove** appears then without lifting your finger, drag the widget into **X Remove**.

Downloaded from www.vandenborre.be

Task Manager

Task Manager is an easy and quick way to close running apps. It effectively cleans your cache and frees more cache space for your PadFone.

To use Task Manager, swipe your screen to the right.



Additional options:

- To resize Task Manager, touch and hold anywhere on the app until the resize border appears. Touch and drag the sizing handle to adjust to your preferred screen size. You can do this to create additional room for more apps.
- To remove Task Manager, touch and hold the app until **X Remove** appears, then without lifting your finger, drag the app into **X Remove**.

Downloaded from www.vandenborre.be

Using PadFone 2 Station widgets

Adding widgets

Use widgets to conveniently access useful and fun applications on your PadFone 2 Station's Home Screen. You can find them in the Widgets tab in the All Apps screen, ready to be moved into your Home Screen.

To see your widgets, touch to go to the All apps screen, then touch **Widgets**.

From the main Widgets screen, you can:

- Drag a widget to another screen.
- Swipe left or right to move between screens and view more widgets.

IMPORTANT:

- You may be prompted to perform additional tasks (such as registration, activation) before you can use a selected widget.
- If there is not enough room on the screen where you placed a widget, the widget won't get added to that screen.

To remove a widget:

- Touch and hold the widget until **X Remove** appears then without lifting your finger, drag the widget into **X Remove**.

Downloaded from www.vandenborre.be

ASUS Battery

This special widget shows the individual battery status of your PadFone 2 and PadFone 2 Station by percentage and color. The more battery power, the brighter the color.

1. Touch to go to the All apps screen.
2. Touch **Widgets** to display the widgets menu.
3. Touch and hold **ASUS Battery** to display the ASUS Battery app.

4. The ASUS Quick Setting and the notifications panel also display the battery status. The battery status of the PadFone 2 and PadFone 2 Station are shown separately. When battery is low, the battery icon turns from blue to red with an exclamation mark. There will also be a warning sound to notify you when the battery is running low.